



USER MANUAL

VMS-V-2.2K-12/ VMS-V-3.2K-24

INVERTER / MPPT SCC / AC CHARGER

VERSION: 1.0

Table Of Contents

1	ABOUT THIS MANUAL	3
1.1	PURPOSE	3
1.2	SCOPE	3
2	SAFETY INSTRUCTIONS	3
3	INTRODUCTION	4
3.1	FEATURES	4
3.2	BASIC SYSTEM ARCHITECTURE	4
3.3	PRODUCT OVERVIEW	5
4	INSTALLATION	6
4.1	UNPACKING AND INSPECTION	6
4.2	PREPARATION	6
4.3	MOUNTING THE UNIT	6
4.4	BATTERY CONNECTION	7
4.5	AC INPUT/OUTPUT CONNECTION	9
4.6	PV CONNECTION	10
4.7	FINAL ASSEMBLY	11
4.8	COMMUNICATION CONNECTION	11
5	OPERATION	12
5.1	POWER ON/OFF	12
5.2	OPERATION AND DISPLAY PANEL	12
5.3	LED DISPLAY ICONS	13
5.4	LCD SETTING	15
5.5	DISPLAY SETTINGS	23
5.6	OPERATING MODE DESCRIPTION	26
5.7	BATTERY EQUALIZATION DESCRIPTION	27
5.8	FAULT REFERENCE CODE	29
5.9	WARNING INDICATOR	29
6	CLEARANCE AND MAINTENANCE FOR ANTI-DUST KIT	30
6.1	OVERVIEW	30
6.2	CLEARANCE AND MAINTENANCE	30
7	SPECIFICATIONS	31
	TABLE 1 LINE MODE SPECIFICATIONS	31
	TABLE 2 INVERTER MODE SPECIFICATIONS	32
	TABLE 3 CHARGE MODE SPECIFICATIONS	34
8	TROUBLE SHOOTING	36

1 ABOUT THIS MANUAL

1.1 Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

2 SAFETY INSTRUCTIONS



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

- Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
- CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
- Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
- To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- CAUTION** -- Only qualified personnel can install this device with battery.
- NEVER** charge a frozen battery.
- For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
- Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
- One piece of 150A fuse is provided as over-current protection for the battery supply.
- GROUNDING INSTRUCTIONS** --This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
- Warning!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

3 INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, solar charger and battery charger to offer uninterrupted power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

3.1 Features

- Pure sine wave inverter
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Auto restart while AC is recovering
- Overload/Over temperature/short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function
- WIFI/GPRS(Optional)
- Can connect to lithium battery

3.2 Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or Utility.
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.





Figure 1 Hybrid Power System

3.3 Product Overview



VMS-V-2.2K-12/VMS-V-3.2K-24

1. LCD display
2. Status indicator
3. Charging indicator
4. Fault indicator
5. Function buttons
6. Power on/off switch
7. AC input
8. AC output
9. PV input
10. Battery input
11. RS-232 communication port

4 INSTALLATION


4.1 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

- The unit x 1
- User manual x 1
- DC Fuse x 1
- Ring terminal x 1

4.2 Preparation

Before connecting all wirings, please take off bottom cover by removing two screws as shown below.



VMS-V-2.2K-12/VMS-V-3.2K-24

4.3 Mounting the Unit

- Consider the following points before selecting where to install:
- Do not mount the inverter on flammable construction materials.
 - Mount on a solid surface
 - Install this inverter at eye level in order to allow the LCD display to be read at all times.
 - For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
 - The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
 - The recommended installation position is to be adhered to the wall vertically.
 - Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.

 **SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.**

Install the unit by screwing two screws. It's recommended to use M4 or M5 screws.



4.4 Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical ampereage in below table as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified personnel.
WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable as below.

Recommended battery cable size:


Wire Size	Cable (mm ²)	Torque value (max)
1 x 4AWG	22	2 Nm

Please follow below steps to implement battery connection:

1. Remove insulation sleeve 18 mm for positive and negative conductors.
2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.



4. Connect all battery packs as below chart.



5. Insert the battery wires flatly into battery connectors of inverter and make sure the bolts are tightened with torque of 2 Nm in clockwise direction. Make sure polarity at both the battery and the inverter/charge is correctly connected and conductors are tightly screwed into the battery terminals.
Recommended tool: #2 Pozz Screwdriver



⚠ WARNING: Shock Hazard

Installation must be performed with care due to high battery voltage in series.

⚠ CAUTION!!

Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

4.5 AC Input/OutputConnection

CAUTION!! Before connecting to AC input power source, please install a **separate** AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 10A for 1.5kw and 32A for 2.4kw and 50A for 5KVA.

CAUTION!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC Input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires

Model	Gauge	Torque Value
VMS-V-2.2K-12V/VMS-V-3.2K-24	14 AWG	0.5~0.8Nm


Please follow below steps to implement AC input/output connection:

1. Before making AC input/output connection, be sure to open DC protector or disconnector first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3 mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⚡) first.

⚡ - Ground (yellow-green)

L - LINE (brown or black)

N - Neutral (blue)



⚠ WARNING:

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.

Be sure to connect PE protective conductor (⚡) first.

⚡ - Ground (yellow-green)

L - LINE (brown or black)

N - Neutral (blue)



5. Make sure the wires are securely connected.

CAUTION: Appliances such as air conditioner are required at least 2-3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

4.6. PV Connection

CAUTION: Before connecting to PV modules, please install **separately** a DC circuit breaker between inverter and PV modules.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Wire Size	Torque value (max)
VMS-V-2.2K-12	1x16AWG	1.2 Nm
VMS-V-3.2K-24	1 x 12AWG	

PV Module Selection:

- When selecting proper PV modules, please be sure to consider below parameters:
1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
 2. Open circuit Voltage (Voc) of PV modules should be higher than min. battery voltage.

INVERTER MODEL	Max. PV Array Open Circuit Voltage	Max. PV Array MPPT Voltage Range
VMS-V-2.2K-12	500Vdc	120Vdc~450Vdc
VMS-V-3.2K-24	450Vdc	80Vdc~430Vdc

Take 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed as below table.

Solar Panel Spec. (reference)	SOLAR INPUT		Total Input power
	(Min in serial)	Qty of panels	
- 250Wp, 1Vdc	4 pcs, max. in serial; 13 pcs	4 pcs	1000W
- Vmp: 8.3A	4 pcs in serial	6 pcs	1500W
- Voc: 37.7Vdc	6 pcs in serial	8 pcs	2000W
- Isc: 8.4A	12 pcs in serial	12 pcs	3000W
- Cells: 60	13 pcs in serial	13 pcs	3250W
	8 pieces in serial and 2 sets in parallel	16 pcs	4000W
	10 pieces in serial and 2 sets in parallel	20 pcs	5000W

PV Module Wire Connection

Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10 mm for positive and negative conductors.
2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.



4.7 Communication Connection

1. Wi-Fi cloud communication (option):

Please use supplied communication cable to connect to inverter and Wi-Fi module. Download APP and installed from APP store, and refer to "Wi-Fi Plug Quick Installation Guideline" to set up network and registering. The inverter status would be shown by mobile phone APP or webpage of computer.


2. GPRS cloud communication (option):

Please use supplied communication cable to connect to inverter and GPRS module, and then applied external power to GPRS module. Download APP and installed from APP store, and refer to "GPRS RTU Quick Installation Guideline" to set up network and registering. The inverter status would be shown by mobile phone APP or webpage of computer.

4. Check correct polarity of wire connection from PV modules and PV input connectors. Then, connect positive pole (+) of connection wire to positive pole (+) of PV input connector. Connect negative pole (-) of connection wire to negative pole (-) of PV input connector.
Recommended tool: 4mm blade screwdriver

5 OPERATION

5.1 Power ON/OFF




Side view of unit

Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the bottom of the case) to turn on the unit.

5.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.



LCD display

Function keys

Function key	Description
ESC	To exit setting mode
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode

5.3 LCD Display/Icons



Icon	Function description
Input Source Information	
	Indicates the AC input.
	Indicates the PV input.
	Indicate input voltage, input frequency, PV voltage, charger current (if PV in charging for 3K models), charger power, battery voltage.
Configuration Program and Fault Information	
	Indicates the setting programs.
	Indicates the warning and fault codes.
	Warning: flashing with warning code.
	Fault: lighting with fault code
Output Information	
	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.
Battery Information	
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.
In AC mode, it will present battery charging status.	
Status	LCD Display 4 bars will flash in turns. Bottom bar will be on and the other three bars will flash in turns.
Battery voltage	< 2V/cell
Constant	2 ~ 2.083V/cell
Current mode /	2.083 ~ 2.167V/cell
Constant	> 2.167 V/cell
Voltage mode	Bottom three bars will be on and the top bar will flash.
Floating mode. Batteries are fully charged.	4 bars will be on.

In battery mode, it will present battery capacity.		Battery Voltage	LCD Display
Load > 50%	< 1.85V/cell		
	1.85V/cell ~ 1.933V/cell		
	1.933V/cell ~ 2.017V/cell		
	> 2.017V/cell		
Load < 50%	< 1.892V/cell		
	1.892V/cell ~ 1.975V/cell		
	1.975V/cell ~ 2.058V/cell		
> 2.058V/cell			

Load Information	
	Indicates overload.
	Indicates the load level by 0-24%, 25-49%, 50-74% and 75-100%.
	0%~24%
	25%~49%
	50%~74%
	75%~100%

Mode Operation Information	
	Indicates unit connects to the mains.
	Indicates unit connects to the PV panel.
	Indicates load is supplied by utility power.
	Indicates the utility charger circuit is working.
	Indicates the DC/AC inverter circuit is working.

Mute Operation	
	Indicates unit alarm is disabled.

5.4 LCD Setting

After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press "Up" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

Setting Programs:		Selectable option
Program	Description	
00	Exit setting mode	Escape 00 ESC
		Utility first (default) 01 USB
01	Output source priority: To configure load power source priority	Solar first 01 SUB
		SBU priority 01 SBU
02	Maximum charging current: To configure total charging current for solar and utility chargers. (Max charging current = utility charging current + solar charging current)	10A 02 10 20A 02 20 30A 02 30 40A 02 40

	50A 02 50	60A (default) 02 60
	70A 02 70	80A 02 80
03	Appliances (default) 03 APPL	If selected, acceptable AC input voltage range will be within 90-280VAC.
	UPS 03 UPS	If selected, acceptable AC input voltage range will be within 170-280VAC.
	AGM (default) 05 AGM	Flooded 05 FLD
05	User-Defined 05 USE	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29.
06	Restart disable (default) 06 LFD	Restart enable 06 LFE
07	Restart disable (default) 07 LFD	Restart enable 07 LFE
09	50Hz (default) 09 50	60Hz 09 60
	220V 10 220	230V (default) 10 230
10	240V 10 240	
	2A 11 2A	10A 11 10A
	20A 11 20A	30A (default) 11 30A
11	40A 11 40A	50A 11 50A
	Maximum utility charging current Note: If setting value in program 02 is smaller than that in program 11, the inverter will apply charging current from program 02 for utility charger.	

	60A 11 60A	70A (60V/12V/24V/32KW/4V) 11 70A	80A (60V/12V/24V/32KW/4V) 11 80A
	Available options in 2.0 kW 12V model:		
	10.5V 12 10.5	11.0V 12 11.0	BATT 12 11.0
	11.5V (default) 12 11.5	12.0V 12 12.0	BATT 12 12.0
	12.5V 12 12.5	13.0V 12 13.0	BATT 12 13.0
	13.5V 12 13.5	14.0V 12 14.0	BATT 12 14.0
	14.5V 12 14.5	15.0V 12 15.0	BATT 12 15.0
	Available options in 2.4kW 24V model:		
	22.0V 12 22.0	22.5V 12 22.5	BATT 12 22.5
	23.0V (default) 12 23.0	23.5V 12 23.5	BATT 12 23.5
	24.0V 12 24.0	24.5V 12 24.5	BATT 12 24.5
	25.0V 12 25.0	25.5V 12 25.5	BATT 12 25.5
12	Setting voltage point back to utility source when selecting "SBU priority" or "Solar first" in program 01.		










		Available options in 3.2KW 48V/5.2KW 48V model:	
44V	12	MTT 44	45V 12 MTT 45
46V (default)	12	MTT 46	47V 12 MTT 47
48V	12	MTT 48	49V 12 MTT 49
50V	12	MTT 50	51V 12 MTT 51
		Available options in 2.0KW 12V model:	
Battery fully charged	13	MTT FUL	12.0V 13 MTT 120
12.5V	13	MTT 125	13.0V 13 MTT 130
13.5V (default)	13	MTT 135	14.0V 13 MTT 140
14.5V	13	MTT 145	15.0V 13 MTT 150
15.5V	13	MTT 155	16.0V 13 MTT 160
16.5V	13	MTT 165	17.0V 13 MTT 170
		Available options in 2.4KW 24V model:	
Battery fully charged	13	MTT FUL	24V 13 MTT 240

Setting voltage point back to battery mode when selecting "SBU priority" or "Solar first" in program 01.

		Available options in 3.2KW 48V/5.2KW 48V model:	
24.5V	13	MTT 245	25V 13 MTT 250
25.5V	13	MTT 255	26V 13 MTT 260
26.5V	13	MTT 265	27V (default) 13 MTT 270
27.5V	13	MTT 275	28V 13 MTT 280
28.5V	13	MTT 285	29V 13 MTT 290
		Available options in 3.2KW 48V/5.2KW 48V model:	
Battery fully charged	13	MTT FUL	48V 13 MTT 480
49V	13	MTT 490	50V 13 MTT 500
51V	13	MTT 510	52V 13 MTT 520
53V	13	MTT 530	54V (default) 13 MTT 540
55V	13	MTT 550	56V 13 MTT 560
57V	13	MTT 570	58V 13 MTT 580



16	Charger source priority: To configure charger source priority	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below: Utility first <u>16</u> <u>CUE</u>	Utility will charge battery as first priority. Solar energy will charge battery only when utility power is not available.
		Solar first <u>16</u> <u>CSO</u>	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
18	Alarm control	Solar and Utility (default) <u>18</u> <u>SNU</u>	Solar energy and utility will charge battery at the same time.
		Only Solar <u>18</u> <u>OSO</u>	Solar energy will be the only charger source no matter utility is available or not.
19	Auto return to default display screen	If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient. Alarm on (default) <u>19</u> <u>BON</u>	
		Return to default display screen (default) <u>19</u> <u>ESP</u>	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute.
20	Backlight control	Stay at latest screen <u>20</u> <u>HEP</u>	If selected, the display screen will stay at latest screen user finally switches.
		Backlight on (default) <u>20</u> <u>LON</u>	Backlight off <u>20</u> <u>LOF</u>
22	Beeps while primary source is interrupted	Alarm on (default) <u>22</u> <u>AON</u>	Alarm off <u>22</u> <u>AOF</u>
		Bypass disable (default) <u>23</u> <u>BYD</u>	Bypass enable <u>23</u> <u>BYE</u>
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.		



25	Record Fault code	Record enable (default) <u>25</u> <u>FEN</u>	Record disable <u>25</u> <u>FDS</u>
		2.0KW 12V default setting: 14.1V <u>CU</u> <u>26</u> <u>14.1</u>	
26	Bulk charging voltage (C.V voltage)	2.4KW 24V/3.2KW 24V default setting: 28.2V <u>CU</u> <u>26</u> <u>28.2</u>	
		3.2KW 48V/5.2KW 48V default setting: 56.4V <u>CU</u> <u>26</u> <u>56.4</u>	
27	Floating charging voltage	If self-defined is selected in program 5, this program can be set up. Setting range is from 12.5V to 15.5V for 2.0KW 12V model and 25.0V to 31.5V for 2.4KW 24V/3.2KW 24V model and 48.0V to 61.0V for 3.2KW 48V/5.2KW 48V model. Increment of each click is 0.1V. 2.0KW 12V default setting: 13.5V <u>FLU</u> <u>27</u> <u>13.5</u>	
		2.4KW 24V/3.2KW 24V default setting: 27.0V <u>FLU</u> <u>27</u> <u>27.0</u>	
29	Low DC cut-off voltage	3.2KW 48V/5.2KW 48V default setting: 54.0V <u>FLU</u> <u>27</u> <u>54.0</u>	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 12.5V to 15.5V for 2.0KW 12V model and 25.0V to 31.5V for 2.4KW 24V/3.2KW 24V model and 48.0V to 61.0V for 3.2KW 48V/5.2KW 48V model. Increment of each click is 0.1V. 2.0KW 12V default setting: 10.0V <u>LOW</u> <u>29</u> <u>10.0</u>	
29	Low DC cut-off voltage	2.4KW 24V/3.2KW 24V default setting: 20.0V <u>LOW</u> <u>29</u> <u>20.0</u>	



30	Battery equalization	<p>3.2KW 48V/5.2KW 48V default setting: 40.0V </p> <p>If self-defined is selected in program 5, this program can be set up. Setting range is from 10.0V to 12.0V for 2.0KW 12V model and 20.0V to 24.0V for 2.4KW 24V/3.2KW 24V model and 42.0V to 48.0V for 3.2KW 48V/5.2KW 48V model. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.</p> <p>Battery equalization Battery equalization disable (default)  </p> <p>If "Hooded" or "User-Defined" is selected in program 05, this program can be set up.</p> <p>2.0KW 12V default setting: 14.6V </p> <p>2.4KW 24V/3.2KW 24V default setting: 29.2V </p> <p>3.2KW 48V/5.2KW 48V default setting: 58.4V </p> <p>Setting range is from 13.0V to 15V for 2.0KW 12V model and 25.0V to 30V for 2.4KW 24V/3.2KW 24V model and 48.0V to 61.0V for 3.2KW 48V/5.2KW 48V model. Increment of each click is 0.1V.</p> <p>60min (default) Setting range is from 5min to 900min.  Increment of each click is 5min.</p> <p>120min (default) Setting range is from 5min to 900 min.  Increment of each click is 5 min.</p> <p>30days (default) Setting range is from 0 to 90 days.  Increment of each click is 1 day</p> <p>Enable Disable (default)  </p> <p>If equalization function is enabled in program 30, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD main page will show "EQ". If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 35 setting. At this time, "EQ" will not be shown in LCD main page.</p>
31	Battery equalization voltage	
33	Battery equalized time	
34	Battery equalized timeout	
35	Equalization interval	
36	Equalization activated immediately	



5.5 DisplaySetting

The LCD display information will be switched in turns by pressing "Up" or "DOWN" key. The selectable information is switched as below order: input voltage, output voltage, PV voltage, charging current, charging power, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, load in Watt, DC discharging current, main CPU Version.




Selectable information	LCD display
Input voltage/Output voltage (Default Display Screen)	
Input frequency	
PV voltage	
PV current	
PV power	




Charging current	<p>AC and PV charging current=50A</p>  <p>PV charging current=50A</p>  <p>AC charging current=50A</p> 
Charging power	<p>AC and PV charging power=500W</p>  <p>PV charging power=500W</p>  <p>AC charging power=500W</p>  <p>Battery voltage=25.5V, output voltage=230V</p> 
Battery voltage and output voltage	

Output frequency	<p>Output frequency=50Hz</p> 
Load percentage	<p>Load percent=70%</p> 
Load in VA	<p>When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.</p>  <p>When load is larger than 1kVA (>=1kVA), load in VA will present x.xxVA like below chart.</p> 
Load in Watt	<p>When load is lower than 1kW, load in W will present xxxW like below chart.</p>  <p>When load is larger than 1kW (>=1kW), load in W will present x.xxW like below chart.</p> 

Battery voltage/DC discharging current	Battery voltage=25.5V, discharging current=1A 
Main CPU version checking	Main CPU version 20.11 

5.6 Operating Mode Description

Operation mode	Description	LCD display
Standby mode / Power saving mode	No output is supplied by the unit but it still can charge batteries.	Charging by utility and PV energy. 
Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.		Charging by utility. 
		Charging by PV energy. 
		No charging. 
		Charging by utility and PV energy. 
Fault mode	PV energy and utility can charge batteries.	Charging by utility. 
Note: *Fault mode: Errors are caused by inside circuit error or external reasons such as over-temperature, output short circuited and so on.		Charging by PV energy. 
		No charging.

Operation mode	Description	LCD display
	The unit will provide output power from the mains. It will also charge the battery at line mode.	Charging by utility and PV energy. 
Line Mode	The unit will provide output power from the mains. It will also charge the battery at line mode.	Charging by utility. 
	If "solar first" is selected as output source priority and solar energy is not sufficient to provide the load, solar energy and the utility will provide the loads and charge the battery at the same time.	Power from battery and PV energy. 
	The unit will provide output power from battery and PV power.	Power from battery and PV energy. 
Battery Mode	The unit will provide output power from battery and PV power.	PV energy will supply power to the loads and charge battery at the same time. 
		Power from battery only. 

5.7 Battery Equalization Description


Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.

• How to Apply Equalization Function

- You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:
1. Setting equalization interval in program 35.
 2. Active equalization immediately in program 36.


• **When to Equalize**

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




• **Equalize charging time and timeout**

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.



5.8 Fault Reference Code

Fault Code	Fault Event	Icon on
01	Fan is locked when inverter is off.	
02	Over temperature	
03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short circuited or over temperature is detected by internal converter components.	
06	Output voltage is too high.	
07	Overload time out	
08	Bus voltage is too high	
09	Bus soft-start failed	
51	Over current or surge	
52	Bus voltage is too low	
53	Inverter soft start failed	
55	Over DC voltage in AC output	
57	Current sensor failed	
58	Output voltage is too low	
59	PV voltage is over limitation	

5.9 Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	
07	Overload	Beep once every 0.5 second	
10	Output power derating	Beep twice every 3 seconds	
15	PV energy is low.	Beep twice every 3 seconds	
E9	Battery equalization	None	

6 SPECIFICATIONS

Table 1 Line Mode Specifications


INVERTER MODEL	VMS-V-2.2K-12/VMS-V-3.2K-24
Input Voltage Waveform	Sinusoidal (utility or generator)
Nominal Input Voltage	230Vac
Low Loss Voltage	170Vac±7V (UPS); 90Vac±7V (Appliances)
Low Loss Return Voltage	180Vac±7V (UPS); 100Vac±7V (Appliances)
High Loss Voltage	280Vac±7V
High Loss Return Voltage	270Vac±7V
Max AC Input Voltage	300Vac
Nominal Input Frequency	50Hz / 60Hz (Auto detection)
Low Loss Frequency	40±1Hz
Low Loss Return Frequency	42±1Hz
High Loss Frequency	65±1Hz
High Loss Return Frequency	63±1Hz
Output Short Circuit Protection	Circuit Breaker
Efficiency (Line Mode)	>95% (Rated R load, battery full charged)
Transfer Time	10ms typical (UPS); 20ms typical (Appliances)
Output power derating:	 <p>When AC input voltage drops to 170V, the output power will be derated.</p>

Table 2 Inverter Mode Specifications

INVERTER MODEL	VMS-V-2.2K-12	VMS-V-3.2K-24
Rated Output Power	2000W	3200W
Output Voltage Waveform	Pure Sine Wave	
Output Voltage Regulation	230Vac±5%	
Output Frequency	50Hz	
Peak Efficiency	91%	
Overload Protection	5s@ >150% to ad; 10s@ 110% - 150% to ad	
Surge Capacity	2* rated power for 5 seconds	
Nominal DC Input Voltage	12 Vdc	24 Vdc
Cold Start Voltage	11.5Vdc	
Low DC Warning Voltage	23.0Vdc	
@ load < 50%	11.0Vdc	
@ load > 50%	10.5Vdc	
Low DC Warning Return Voltage	22.5Vdc	
@ load < 50%	11.5Vdc	
@ load > 50%	11.0Vdc	
Low DC Cut-off Voltage	22.0Vdc	
@ load < 50%	10.2Vdc	
@ load > 50%	9.6Vdc	
High DC Recovery Voltage	14.0Vdc	
High DC Cut-off Voltage	16.0Vdc	
No Load Power Consumption	<25W	

Table 3 Charge Mode Specifications

Utility Charging Mode		VMS-V-2.2K-12	VMS-V-3.2K-24
INVERTER MODEL		3-Step	
Charging Algorithm		60Amp (@V _{bat} =230Vdc)	
AC Charging Current (Max)		14.6	29.2
Bulk Charging Flooded Battery		14.1	28.2
Voltage AGM / Gel Battery		13.5Vdc	27Vdc
Floating Charging Voltage			
Charging Curve			
MPPT Solar Charging Mode		VMS-V-2.2K-12	VMS-V-3.2K-24
INVERTER MODEL		3200W	
Max. PV Array Power		2000W	3200W
Nominal PV Voltage		240Vdc	
PV Array MPPT Voltage Range		40~400Vdc	
Max. PV Array Open Circuit Voltage		400Vdc	
Max Charging Current (AC charger plus solar charger)		80Amp	

Table 4 General Specifications

INVERTER MODEL		VMS-V-2.2K-12	VMS-V-3.2K-24
Safety Certification			
Operating Temperature Range		-10°C to 50°C	
Storage temperature		-15°C - 60°C	
Humidity		5% to 95% Relative Humidity (Non-condensing)	
Dimension (D*W*H) . mm		348X270X95	
Net Weight . kg		4	5

8 TROUBLE SHOOTING

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low (<1.91V/Cell)	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1. The battery voltage is far too low. (<1.4V/Cell) 2. Internal fuse tripped.	1. Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery.
	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
Main exists but the unit works in battery mode.	Green LED is flashing.	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPSe Appliance)
	Green LED is flashing.	Set "Solar First" as the priority of output source.	Change output source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
	Fault code 07	Overload error. The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.
	Fault code 02	Temperature of internal converter component is over 120°C. Internal temperature of inverter component is over 100°C. Battery is over-charged.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. Return to repair center.
Buzzer beeps continuously and red LED is on.	Fault code 03	The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.
	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	1. Reduce the connected load. 2. Return to repair center.
	Fault code 08/09/59/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit. If the error happens again, please return to repair center.
	Fault code 52	Bus voltage is too low.	
	Fault code 55	Output voltage is unbalanced.	